Screw Terminal (M3 x 96)

EPD-96



* Specifications, color and design of the products are subject to change without notice.

Features

Up to 96 signal lines can be connected.

A signal line from an external device can be connected to the terminal simply by using screws.

The optional cable can be used to connect easily to the board/card.

Optimized configuration of board wiring.

Signal banks can be mounted on DIN rails.

The products is a general purpose terminal fastened with screws, which relays the I/O wirings of CONTEC interface board/card or card with a 96-pin half-pitch connector.

The pins in connector correspond to their respective terminals on the terminal strips on a one-to-one basis, allowing you to easily connect the board/card to an external device via the terminal strips.

Note: To connect a board/card to the accessory, you need the separately priced option cable.

Specification

Item	Specification		
Rated isolated voltage	125VAC, 125VDC		
Rated current	1A		
Compatible wiring	2mm²(Max.)		
Isolated resistance	100M Ω or later		
Voltage resistance	1000VAC, 60Hz, One minute		
Compatible pins	Crimp-style pins, Max. diameter 7.2mm		
Connector	PCR-E96MD+ (mfd. by HONDA) equivalent		
Compatible rail	35mm (wide) DIN rail		
Operating conditions	0 - 50°C, 10 - 90%RH (No condensation)		
Weight	360g		

Packing List


EPD-96 main unit...1 User's Guide...1

⚠ CAUTION

The option cable is not appended to the interface board/card and this product. Cable differs according to board/card used. Be sure to check the manual or visit the CONTEC's Web site to buy an appropriate one.

EPD-96 1


Physical View and Dimensions



Wiring Diagram

Terminal TB1 No.		nector No.	TI	Terminal TB2 No.	
A01	48	96	B01		
A02	47	95		B02	
A03	46	94	B03		
A04	45	93		B04	
A05	44	92	B05		
A06	43	91		B06	
A07	42	90	B07		
A08	41	89		B08	
A09	40	88	B09		
A10	39	87		B10	
A11	38	86	B11		
A12	37	85		B12	
A13	36	84	B13		
A14	35	83		B14	
A15	34	82	B15		
A16	33	81		B16	
A17	32	80	B17		
A18	31	79		B18	
A19	30	78	B19		
A20	29	77		B20	
A21	28	76	B21		
A22	27	75		B22	
A23	26_	74	B23		
A24	25	73		B24	
A25	24	72	B25		
A26	23	71		B26	
A27	22	70	B27		
A28	21	69		B28	
A29	20	68	B29	Doo	
A30	19	67	Dos	B30	
A31	18	66	B31	Doo	
A32	17	65	Doo	B32	
A33	16	64	B33	D0.4	
A34	15	63	Doz	B34	
A35 A36	14	62	B35	Dog	
	13	61	Doz	B36	
A37 A38	12	60	B37	Doo	
	11 10	59	B39	B38	
A39		58	Бээ	D40	
A40	9	57	D41	B40	
A41	8	56	B41	D 40	
A42	7	55	D 49	B42	
A43 A44	6	54	B43	D 4 4	
A45	5	53	B45	B44	
A45 A46	3	52	D40	B46	
	$\frac{3}{2}$	51	B47	D40	
A47			D4 /	D40	
A48	1	49		B48	

EPD-96 Connections



- (1) Connect the interface board/card and the terminal unit using the separately available option cable.
- (2) Identify the destination for connection on the terminal unit and connect the signal line from the external equipment. You can provide connection easily just by tightening the screws.

EPD-96 2